

### AUX-IN:

For other compatible music devices or your MP3/MP4 players, use the audio cable (not included) to connect from the device's "Line Out" to the "Aux In" of this device to enjoy playing music.

Under any playing mode, When you use the audio cable to connect the device, it will auto switch to the AUX mode.

Under AUX mode, all functions can be controlled by external device.

### Battery Charging:

1. Power off the unit, put the provided adapter into the charge slot of unit, the red charging indicator keep lighting.
2. Charge time should be 5-6 hours. When charging full, the indicator light will switch off.
3. In order to prolong the life of battery, please do not charge more than 8 hours.

### Note:

1. The playtime depends on how hard the unit is working. Heavy, loud, bass music will use more energy.
2. The built-in rechargeable battery is not replaceable. Do not remove or replace it, do not throw in the fire.
3. When cleaning the product, use a soft dry cloth. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.

### Recording function:

1. Make sure the unit is switched on, and there is a USB memory stick or TF card inserted in the slot.
2. Plug and test the microphone upon plugging. The device is ready to record once your voice is audible from the speaker.
3. Press the button 'REC' on the remote controller to start/stop recording, you are freely to rec what you want.

### Playing music from USB disk and Micro SD card:

1. Turn the Power button to "ON".
2. Insert USB flash disk or Micro SD card into slot, the music stored will be played automatically.
3. Under playing mode, short press Previous or Next button to select songs you like, Or press the VOL-/ VOL+ button to adjust volume down and up. PLAY/PAUSE to play or pause.
4. Please turn the Power button to "OFF" while without use.

Remark: Under Bluetooth playing mode, insert USB disk or Micro SD card will disconnect the Bluetooth and switch to play the USB disk or Micro SD card. You can press the MODE button to switch to Bluetooth mode again.

### How to Use FM Radio:

1. Turn the power button to "ON", press the "MODE" button to FM radio mode.
2. Under playing mode, short press "Play/pause" button to auto search the FM Channel and store it automatically.
3. Press Previous or Next button to change the stored FM channel.

Under FM radio state, to get a better FM signal, please insert a audio cable (not included) as antenna.

## XEMPT PARTY PITCHER MINI



## INSTRUCTION MANUAL

For correctly operating, please read this manual carefully before using. We are not responsible for consequence caused by fault or oversight of this manual.

### FEATURES :

- Outdoor HIFI Bluetooth Radio
- Output very clear sound and dynamic sound effect
- With A2DP/AVRCP Bluetooth, wireless stream music from any Bluetooth-enabled device such as your mobile phone, notebook, iPhone or iPad
- Secure simple pairing for user-friendly operating
- 10 meters operating range
- With USB and Micro TF supporting
- With Line-in function, suitable for PC/MID/TV and other audio device
- Built-in lead-acid rechargeable battery 12V 5.5AH
- With FM Radio
- TWS function
- RGB music beat light


### ACCESSORIES:

- User manual \*1pc
- Wireless microphone \*1pc
- Power adapter \*1pc
- Remote controller \*1pc

### SPECIFICATION:

Bluetooth range	up to 10 meters
Speaker:	Woofer Size:8 inch
Output:	80W
Connections:	USB disk, Micro SD card reader, Microphone input jack Aux-in 3.5mm jack connection, Guitar input jack
Power supply:	Built-in rechargeable lead-acid battery 12V 5.5AH
Play time:	5hrs with 80% volume/6hrs with 50% volume
Recharge power:	15V/4A
Product size:	310(L) *300(W) * 520(H) mm
Charge time:	5-6 hours( 15V/4A)

### INSTRUCTION FOR APPEARANCE AND KEY :



1. USB / TF/AUX INPUT  
MICROPHONE INPUT JACK 1/2  
GUITAR INPUT JACK
2. POWER ON/OFF
3. SELECT MIC OR GUITAR FUNCTION  
TO ADJUST MIC OR GUITAR VOLUME SOUND  
MODE(FM/AUX/BLUETOOTH/USB  
/TF/TWS MODE)  
INCREASE/REDUCE MIC VOLUME

4. INCREASE/DECREASE  
THE MASTER VOLUME  
TREBLE/ BASS  
LIGHT SW
5. REPEAT  
PREVIOUS SONG  
PLAY/PAUSE  
NEXT SONG

### REMOTE FUNCTION DECLARATION:

1. MUTE/MODE(LINE IN/USB/TF/AUX/BLUETOOTH/FM)
2. 0-9
3. ECHO+/ECHO-/ EQ/ GUITAR VOLUME+/GUITAR VOLUME-  
PREVIOUS SONG/CHANNEL  
PAUSE/PLAY  
NEXT SONG/CHANNEL
4. TREBLE+/TREBLE-
5. VOLUME+/VOLUME-/MIC VOLUME+/ MIC VOLUME-/LIGHT SW
6. BASS+/BASS-
7. MIC TREBLE+/TREBLE-  
MIC BASS+/BASS-
8. MIC PRIORITY/REPEAT/REC/FOLDER



### Bluetooth connection:

1. Turn the power button to "ON". In the front panel, press the mode button to launch the Bluetooth application. The system voice of the device will say "Bluetooth mode".
2. Activate Bluetooth of mobile phone and search for device name " XMT PP05 "
3. then connect it. The system voice says "Bluetooth connected" once connected successfully.
4. Play the music from your mobile phone and enjoy.
5. Press Previous or Next button on the device or on Mobile phone to select songs you like.
6. Press Play/pause button on the device or on Mobile phone to play/pause the music.
7. Use the Bluetooth device to adjust volume up and down. Or turn knob to adjust volume down and up.

### TWS FUNCTION :

1. Turn on two identical speakers you want to pair, please noted they must be the same BT pairing name, both under BT mode. Only need to set one of the two units;
2. Long press "NEXT" button until you hear the system voice "bluetooth connected", then successfully paired;
3. Make Bluetooth connection with your mobile phone, play music and enjoy true wireless stereo sound effect.